

Schnelldorfer LinearWeld



Quick Start Guide

Includes how to:

Start Up/Shut Down

Set Up Jobs

Solve Problems

Store Data

Perfect Welds Together

Schnelldorfer LinearWeld

Table of Contents

1. Power Up & Shut Down
2. Maintenance Checklist
3. Job Set-Up
4. Problems & Solutions
5. SeamWelder Data Storage
6. Welding Parameters

LinearWeld Power Up Procedure

- Open gas supply 1 revolution, all bottles (*Picture 1*)
- Open compressed air valve (**pg. 33 sec. 7.2**) (*Picture 2*)
- Turn electric on at panel, wait for control to boot up (**pg. 35 sec. 8.1.2**) (*Picture 3*)
- Press Plant On button (**pg. 37 sec. 8.2.1**) (*Picture 4*)
- Press the Next button on the display screen (**pg. 41 sec. 8.4.4**) (*Picture 5*)
- Press the Home Position Travel button on display screen (**pg. 41 sec. 8.4.5 step 1**) (*Picture 6*)
- Press the Start button on the display screen (**pg. 42 sec. 8.4.5 step 2**) (*Picture 7*)
- Press the Home Icon button on the display screen (**pg. 42 sec. 8.4.5 step 3**) (*Picture 7*)
- Press the Gas Test button on the display screen (**pgs. 44 & 45 sec. 8.4.2.1**) (*Picture 8*)

LinearWeld Power Up Procedures



Picture 1



Picture 2



Picture 3



Picture 4


LinearWeld Power Up Procedures



Picture 5



Picture 6



Picture 7



Picture 8

LinearWeld Power Down Procedure

- Save any changes made to existing program (pg. 66 sec. 8.4.2.11.2)
- Press Plant Off button (pg. 37 sec. 8.2.2) (Picture 1)
- Clean welding blocks and clamping fingers (Picture 2)
- Close gas supply, all bottles (Picture 3)
- Close compressed air valve (pg. 33 sec. 7.2)
- Turn electric Off at panel (pg. 35 sec. 8.1.2) (Picture 4)

LinearWeld Power Down Procedures



Picture 1



Picture 2



Picture 3



Picture 4

Maintenance Checklist LinearWeld

POST ON THE MACHINE CONTROL PANEL FOR DAILY VIEWING

DAILY MAINTENANCE:

Visual Inspection:

1. Nozzle
 - *Remove*, inspect for cracks, clean off burn marks
 - *Replace*, if cracked
2. Tungsten stick
 - *Check* height
 - *Grind* in tungsten grinder, if necessary
 - *Replace*, if necessary
3. Diffuser
 - *Clean* any residue
 - *Look* for clean path for welding gas
 - *Replace* if cleaning does not clear the debris
4. Gas bottles
 - *Check* gas volume remaining in each bottle
 - *Check* Liter pressure to the NimbleSafe – match set-up instructions?
 - *Gas* test – getting good gas pressure at all 4 locations?
5. Check air filter of compressed air input for excessive dirt or moisture
6. Copper
 - *Pull* copper, check gas holes to insure gas flow
 - If badly stained, *clean* copper with rag & acetone
 - use scotch brite gently if necessary
 - *Inspect* for good condition, replace as necessary

WEEKLY MAINTENANCE:

Daily Maintenance, plus **Clean** these devices at least once per week

1. Copper
2. Diffuser
3. Air Filter in air line
4. Filter on Chiller (some chillers do not have a filter)

MONTHLY MAINTENANCE:

Daily & Weekly Maintenance, plus

1. *Check* the air & gas lines for leaks
2. *Replace* the Air Filter for the incoming compressed air
3. *Inspect* the sliding surfaces of the torch axis
 - *Clean & Spray* with a Teflon grease, if necessary

Perfect Welds Together


**Image 1 –
Incorrectly
ground
tungsten in
holder**



**Image 2 –
Diffuser
not
cleaned
regularly**



**Image 3 –
Tungsten
height not
properly set**



Perfect Welds Together

LinearWeld Job Set-Up Procedure

After Power Up procedure

- Press the Gas Test button on the display screen (*Picture 1*)
- Press Open Lock button (pgs. 171-173 sec. 8.4.5) (*Picture 2*)
- Press Center Stop Down button (pgs. 171-173 sec. 8.4.5) (*Pictures 3a and 3b*)
- Load the part (pgs. 171-173 sec. 8.4.5) (*Picture 4*)
- Press Lock Down button (pgs. 171-173 sec. 8.4.5) (*Picture 5*)
- Hold part against end stop (pgs. 171-173 sec. 8.4.5)
- Hold the back side of part against center stop (pgs. 171-173 sec. 8.4.5)
- Clamp back fingers (*Picture 6*) (pgs. 171-173 sec. 8.4.5)
- Push front side of part against center stop (pgs. 171-173 sec. 8.4.5)
- Clamp front fingers once (this is the soft clamp and the center stop will move out of position – (*Picture 7*) (pgs. 171-173 sec. 8.4.5)
- Push front side of part to close gap between front side and back side of the part (*Pictures 8a and 8b*) (pgs. 171-173 sec. 8.4.5)
- Press front fingers again to hard clamp (*Picture 9*) (pgs. 171-173 sec. 8.4.5)
- Manually raise the torch further, at least 2 revolutions using knurled knob (*Picture 10*)
- Remove the torch nozzle (*Picture 11*)
 - If the tip is dirty (see examples – *Pictures 12, 13, 14*)
 - Remove electrode assembly
 - Grind the tip in a tungsten grinder
 - Set the length in the fixture
 - Re-install into the torch assembly
- Remove back shielding nozzle for better sight of the torch tip (*Picture 15*)
- Set electrode height to part (pg. 120 sec. 7.5.7.1) (*Picture 16*)
- Press the Manual Torch Travel button on the display screen (pg. 120 sec. 7.5.7.1) (*Picture 17*)
 - Set Torch Travel distance to Max Travel (pg. 120 sec. 7.5.7.1) (*Picture 18*)
- Position electrode over part (*Picture 19*)
- Press Torch Down button on display screen (*Picture 20*)

- Set electrode needle over the part manually to proper height (approx. 1mm above part) by using a feeler gauge (*Picture 21*)
 - See manual (pgs. 166-167 sec. 8.3.2.1)
- Press the Torch Up button (*Picture 22*)
- Reassemble the torch nozzle & ground (*Picture 23*)
- Press the Torch Down button (*Picture 24*)
- Manually lock the shield gas housing just above the part (*Picture 25*)
- Press the Torch Up button (*Picture 26*)
- Press Return to auto screen (*Picture 27*)
- Load a program - material type & thickness (Possibly part number for special programs or tooling)
 - Press the Load button on the display screen (*Picture 28*)
 - Enter user name (Training level dependent) (*Picture 29*)
 - Enter password (Training level dependent) (*Picture 29*)
 - Press OK button on the display screen (*Picture 30*)
 - Press the Load button on the display screen (*Picture 31*)
 - Choose the correct program (*Picture 32*)
 - Press the Load button on the display screen (*Picture 33*)
 - Press the Yes button on the display screen (*Picture 34*)
- Press the Home Icon button (*Picture 35*)
- Push flashing Start button to start the weld (*Picture 36*)

Job Set-Up Procedures



Picture 1



Picture 2



Picture 3a



Picture 3b



Picture 4



Picture 5

Job Set-Up Procedures (cont.)



Picture 6



Picture 7



Picture 8a



Picture 8b



Picture 9



Picture 10

Job Set-Up Procedures (cont.)



Picture 11



Picture 12




Picture 13



Picture 14

Job Set-Up Procedures (cont.)



Picture 15



Picture 16



Picture 17



Picture 18



Picture 19



Picture 20

Disclaimer – Please always refer to Schnellborfer owner's manual for complete instructions.

Page 6

Job Set-Up Procedures (cont.)



Picture 21



Picture 22



Picture 23



Picture 24

Job Set-Up Procedures (cont.)



Picture 25



Picture 26



Picture 27



Picture 28

Job Set-Up Procedures (cont.)




Picture 29



Picture 30



Picture 31



Picture 32


Job Set-Up Procedures (cont.)



Picture 33



Picture 34



Picture 35



Picture 36

Set-Up Data Page for Each Program Elena LinearWeld

PLEASE KEEP THE SET-UP PAGE IN A BINDER NEAR THE MACHINE SO THE OPERATOR CAN USE THIS TO CORRECTLY SET UP & POSITION THE TOOLING FOR EACH PROGRAM BEING USED

PROGRAM NUMBER: _____

Material Type: _____

Material Thickness: _____

Needle Type: _____

Needle Diameter: _____

Backing Block material: _____

Backing Block Size: _____
(special tool or segment sizes, Back to Front)

Clamp Finger material: _____

Clamp Finger Size: _____

Clamp Finger Distance to Weld Bead: _____ {position copper after 1st test weld}

Weld Gas setting: _____

Trail Gas setting: _____

Backing Gas setting: _____

Clamping Gas setting: _____

Problems and Solutions at Welding with the SeamWeld Machine

Problem: Coloration

- Solution:**
- Switch gas on (flowmeter, machine parameter, valve)
 - Adjust Carrie gas nozzle (direction, after torch)
 - Gas flow times before and after
 - Adjust gas pressure
 - Clean material in front of welding

Problem: Penetration too low

- Solution:**
- More current I-O
 - Lower speed
 - Less wire-filler

Problem: Penetration too high

- Solution:**
- Less current
 - Higher speed
 - More wire-filler

Problem: Hole on the Start Point

- Solution:**
- Less start current I-O
 - Less pre-weld time
 - Higher upslope
 - Adjust start point more in material

Problem: Hole in Welding End

- Solution:**
- Less end current I-E
 - Less post-weld time
 - Lower downslope
 - Higher downslope length
 - Adjust welding-end more in material

Problem: Holes during welding

- Solution:**
- Clamping without gap

- Adjust tungsten in the middle
- Clean material

Problem: No Arc

- Solution:**
- Turn direction (Start point should be lower than welding end)
 - Adjust the Tungsten high (Same distance as material thickness)
 - Switch Arc on (Automatic menu)

Problem: Pores and bad welding

- Solution:**
- Switch gas on
 - Take care on Airflow (Fans, open windows and doors)
 - Choose the right operation (DC- or AC for Aluminum)
 - Change Tungsten (DC- = Blue 30°) (AC = green, point)

Problem: Wire fixed on the welding end

- Solution:**
- Higher cold-wire hold-time
 - Lower cold-wire lead-time
 - Higher cold-wire downslope length

Problem: Welding overlap on one side

- Solution:**
- Adjust Tungsten in the middle
 - Adjust Copper-Clamping-Finger parallel
 - Check if bending is between 60-80% overlapping

Problem: Holes During the Welding

- Solution:**
- Clamping without gap
 - Adjust tungsten in the middle
 - Clean material

Problem: Gap will not close

- Solution:**
- Try to minimize the gap manually and weld with Filler-wire
 - Higher cold-wire speed

Seam Welder Data Storage


Data storage begins on automatic screen (*Picture 1*)

- **Save changes made to an existing program name**
 - Press Return button (*Picture 1*)
 - Press Data Storage (*Picture 2*)
 - Press Store Data Record (*Picture 3*)
 - Enter ID number (*Picture 4*)
 - Press Store (*Picture 4*)
 - Press Yes (*Picture 5*)
 - Question – Do you want to override existing ID Number? (*Picture 6*)
 - Press Yes (*Picture 6*)
 - Press Home Icon button (*Picture 6*)


Save changes to an existing program name



Picture 1



Picture 2



Picture 3



Picture 4




Picture 5



Picture 6

- **Copy a program under a new name**
 - Press Return (*Picture 1*)
 - Press Data Storage (*Picture 2*)
 - Press Data Record Management (*Picture 3*)
 - Select program using blue up or down arrow (*Picture 4*)
 - Press Disc Icon (*Picture 5*)
 - Save As pop up, Change ID number and name (*Picture 6*)
 - Save As pop up, Press OK - New name will appear on the program menu
 - Press Home Icon (*Picture 7*)

Copy a program under a new name



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5



Picture 6



Picture 7

- **Change a program name**
 - Press Return (*Picture 1*)
 - Press Data Storage (*Picture 2*)
 - Press Data Record Management (*Picture 3*)
 - Select program to be changed using the blue up or down arrow (*Picture 4*)
 - Press the B – A Icon (*Picture 5*)
 - Rename pop up, Change the ID number and name (*Picture 6*)
 - Rename pop up, Press OK (*Picture 6*)
 - Press the Home Icon (*Picture 7*)

Change a program name



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5



Picture 6



Picture 7

- **Load programs to and from a Flash Drive**
 - Press Return (*Picture 1*)
 - Press Data Storage (*Picture 2*)
 - Press Data Record Management (*Picture 3*)
 - Press Flash Drive icon – Blue for data from flash drive or Green for data to the flash drive (Password pop up Production management ID number and Password is required) (*Picture 5*)
 - **Use a dedicated Flash Drive for NimbleSafe programs only**
 - **The NimbleSafe will only transfer entire content of Welder on Flash Drive**
 - Press the Home Icon (*Picture 6*)

Load programs to and from a flash drive




Picture 1



Picture 2



Picture 3



Picture 4



Picture 5



Picture 6

Welding Parameter Stainless Steel

Parameter Name	316L 1,2mm Pulse	316L 1,2mm Re to Fr	316L 1,2 PUL Fr>Re	316L 1,5mm Argon	316L 1,5mm Re to fr	316L 2,0mm Pulse	316L 0,3mm	316L 0,5mm	316L 1,0mm	316L 1,5mm	316L 2,0 mm	316L 2,5mm	316L 3,0m m	
Parameter Number	12	13	14	15	16	20	103	105	110	115	120	125	130	
Welding Parameter														
	U nit													
No. of Segments	Segments	1	1	1	1	1	1	1	1	1	1	1	1	
Start point 1	mm	25.77 06	440	13.67 929	8.785 492	440	122.84 86	5	356.5	439.3 382	1	1	0	18
Welding length 1	mm	501.5 795	506.48 42	441.7 457	74	506.4 842	421.05 94	295	502	506.4 842	200	200	200	18 5
Welding Speed	cm/min	70	70	70	65	65	50	150	100	70	60	50	40	25
Gas pre-flowtime	sec	2	2	2	2	2	2	1	2	2	2	2	2	2
Gas after-flowtime	sec	2	2	2	2	2	2	2	2	2	4	4	4	4
Parkposition	mm	300	300	300	300	300	300	0	300	300	0	0	0	0
Gas pre-flowtime torch	sec	2	2	2	2	2	2	2	2	2	2	2	2	2
pre-weldtime	sec	0.1	0.1	0.1	0.1	0.1	0.1	0	0.1	0.1	0.2	0.2	0.2	0.2
Startcurrent I-S	A	40	40	40	40	40	85	8	20	40	90	100	120	17 0
Upslope	sec	0.2	0.2	0.2	0.2	0.2	0.2	0.4	0.2	0.2	0.4	0.4	0.4	0.4
Maincurrent I-O	A	100	95	100	100	100	120	25	65	85	105	130	170	24 0
No. Of Switch length		0	0	0	0	0	0	0	0	0	0	0	1	0
Downslope length	mm	2.5	2.5	2.5	2.5	2.5	2.5	3	3	3	5	5	5	5
Downslope	sec	0.3	0.3	0.3	0.3	0.3	0.3	0.2	0.3	0.3	0.5	0.5	0.2	0.2
End Current I-E	A	25	25	25	25	25	46	6	12	20	80	100	140	14 0
post-weldtime	sec	0.3	0.3	0.3	0.3	0.3	0.1	0	0.1	0.1	0.1	0.1	0.1	0.1
Gas after-flowtime torch	sec	8	8	8	8	8	8	2	8	8	2	2	2	2
Welding Machine Parameter														
Type of Operation	DC- / AC	DC-	DC-	DC-	DC-	DC-	DC-	DC-	DC-	DC-	DC-	DC-	DC-	DC-
Second Current	%	70	70	70	70	70	70	0	70	70	90	90	90	90
Frequency	Hz	65	65	65	65	65	65	0.2	65	65	90	90	90	90
DC-Balance	%	20	20	20	20	20	20	10	10	20	10	10	10	20
AC-Balance	%	0	0	0	0	0	0	0	0	0	0	0	0	0
Pulse	on / off	on	off	on	off	off	off	off	on	on	off	off	on	on
Coldwire Parameter														
Coldwire	on / off	off	off	off	off	off	on	off	off	off	off	o f f	o f f	off
Coldwire delay time	sec	0.1	0.1	0.1	0.1	0.1	0.1	0	0.1	0.1	0	0	0	0
Speed Wirefiller	cm/min	50	50	50	50	50	50	1	50	50	1	1	1	1
No. Of switch length	No.	0	0	0	0	0	0	0	0	0	0	0	0	0
Downslope length	mm	0	0	0	0	0	0	0	0	0	0	0	0	0
Wire Holdtime	sec	0.2	0.2	0.2	0.2	0.2	0.3	0	0.2	0.2	0	0	0	0
Wire Leadtime	sec	0	0	0	0	0	0	0	0	0	0	0	0	0
Tack Parameter														
Tack	on / off	off	off	off	off	off	off	off	off	off	off	off	off	off
No. Of Tacks	No.	5	5	5	5	5	1	1	5	5	1	1	1	1
Tack position 1	mm	400	10	400	10	10	79.8	0	10	10	198	0	0	0
Tack position 2	mm	375	11	375	11	11	0	0	11	11	0	0	0	0
Tack position 3	mm	350	12	350	12	12	0	0	12	12	0	0	0	0
Tack position 4	mm	325	13	325	13	13	0	0	13	13	0	0	0	0
Tack position 5	mm	40	15	40	15	15	0	0	15	15	0	0	0	0
Tack Time	sec	1	1	1	1	1	2	0	1	1	2	0	0	0
Tack Current	A	40	80	40	80	80	80	3	80	80	80	3	3	3
Gas after Flowtime	sec	1	0	1	0	0	0	0	0	0	2	0	0	0
Coldwire	on / off	off	off	off	off	off	off	off	off	off	off	off	off	off
Coldwire Delaytime	sec	0	0	0	0	0	0	0	0	0	0	0	0	0
Coldwire Speed	cm/min	1	1	1	1	1	1	1	1	1	1	1	1	1
Machine Parameter														
Parkposition	on / off	on	on	on	on	on	on	off	on	on	off	off	off	off
Partstop position	mm	0	0	90	90	0	0	190	0	0	190	190	190	90
Back sheelding gas	on / off	on	on	on	on	on	on	on	on	on	on	on	on	on
Carrie gas (sheelding nozzle)	on / off	on	on	on	on	on	on	on	on	on	on	on	on	on
Direction	fr>re / re>fr	re>fr	re>fr	fr>re	fr>re	re>fr	fr>re	fr>re	re>fr	re>fr	fr>re	fr>re	fr>re	fr>re

Welding Parameters - Carbon Steel									
Parameter Name		MS 1,0mm	MS 1,2mm	MS 1,5mm	MS 2,0mm	MS 2,0 mm	MS 2,0 + Wire	MS 2,5mm	MS 3,0mm
Parameter Number		210	212	215	220	221	223	225	230
Welding Parameter									
Welding Parameter	Unit								
No. of Segments	Segments	1	1	1	1	1	1	1	1
Start point 1	mm	2	13.2135	1	1	13.2135	13.2135	1	1
Welding length 1	mm	201	317.451	201	201	317.451	277.7179	200	200
Welding Speed	cm/min	60	45	60	50	38	38	40	30
Gas pre-flowtime	sec	0	0	0	0	0	0	0	0
Gas after-flowtime	sec	0	0	0	0	0	0	0	0
Parkposition	mm	0	0	0	0	0	0	0	0
Gas pre-flowtime torch	sec	2	2	2	2	2	2	2	2
pre-weldtime	sec	0.2	0.2	0.2	0.2	0.2	0.2	0.3	0.3
Startcurrent I-S	A	60	75	75	95	85	85	115	115
Upslope	sec	0.4	0.4	0.4	0.4	0.4	0.4	0.5	0.5
Maincurrent I-O	A	83	123	120	165	160	130	235	235
No. Of Switch length		0	0	0	0	0	0	0	0
Downslope length	mm	3	3	3	2	3	3	2	4
Downslope	sec	0.2	0.3	0.3	0.2	0.3	0.3	0.2	0.6
End Current I-E	A	30	50	50	60	65	65	60	10
post-weldtime	sec	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0
Gas after-flowtime torch	sec	2	2	2	2	2	2	2	5
Welding Machine Parameter									
Type of Operation	DC- / AC	DC-	DC-	DC-	DC-	DC-	DC-	DC-	DC-
Second Current	%	90	90	90	90	90	90	90	90
Frequency	Hz	90	90	90	90	90	90	90	90
DC-Balance	%	10	10	10	10	10	10	10	10
AC-Balance	%	0	0	0	0	0	0	0	0
Pulse	on / off	off	off	off	off	off	off	off	off
Coldwire Parameter									
Coldwire	on / off	off	off	off	off	off	on	off	off
Coldwire delay time	sec	0	0	0	0	0	0.2	0	0
Speed Wirefiller	cm/min	1	1	1	1	1	60	1	1
No. Of switch length	No.	0	0	0	0	0	0	0	0
Downslope length	mm	0	0	0	0	0	3	0	0
Wire Holdtime	sec	0	0	0	0	0	0.3	0	0
Wire Leadtime	sec	0	0	0	0	0	0	0	0
Tack Parameter									
Tack	on / off	off	off	off	off	off	off	off	off
No. Of Tacks	No.	1	1	1	1	1	1	1	1
Tack position 1	mm	0	0	0	0	0	0	0	200
Tack position 2	mm	0	0	0	0	0	0	0	0
Tack position 3	mm	0	0	0	0	0	0	0	0
Tack position 4	mm	0	0	0	0	0	0	0	0
Tack position 5	mm	0	0	0	0	0	0	0	0
Tack Time	sec	0	0	0	0	0	0	0	3
Tack Current	A	3	3	3	3	3	3	3	150
Gas after Flowtime	sec	0	0	0	0	0	0	0	0
Coldwire	on / off	off	off	off	off	off	off	off	off
Coldwire Delaytime	sec	0	0	0	0	0	0	0	0
Coldwire Speed	cm/min	1	1	1	1	1	1	1	1
Machine Parameter									
Parkposition	on / off	off	off	off	off	off	off	off	off
Partstop position	mm	190	90	190	190	90	90	190	190
Back shielding gas	on / off	off	off	off	off	off	off	off	off
Carrie gas (shielding nozzle)	on / off	off	off	off	off	off	off	off	off
Direction	fr>re / re>fr	fr>re	fr>re	fr>re	fr>re	fr>re	fr>re	fr>re	fr>re

Welding Parameters - Aluminum · Brass								
Parameter Name		ALMG3_1,0	ALMG3_1,5	ALMG3_2,0	ALMG_2,5	ALMG3_3,0	AL 1.2	BR 2,0mm
Parameter Number		310	315	320	325	330	512	720
Welding Parameter								
	Unit							
No. of Segments	Segments	1	1	1	1	1	1	1
Start point 1	mm	2	5	2	5	4	15	13.2135
Welding length 1	mm	295	295	295	295	510	280	182.6117
Welding Speed	cm/min	60	60	60	60	40	45	20
Gas pre-flowtime	sec	0	0	0	0	0	2	0
Gas after-flowtime	sec	0	0	0	0	0	2	0
Parkposition	mm	0	0	0	0	0	300	0
Gas pre-flowtime torch	sec	2	2	2	2	2	2	2
pre-weldtime	sec	0.3	0	0.5	1	1	0.1	0.2
Startcurrent I-S	A	40	40	60	40	180	65	75
Upslope	sec	0.2	0.4	0.4	0.4	2	0.2	0.4
Maincurrent I-O	A	100	150	220	200	250	115	170
No. Of Switch length		0	0	0	0	0	0	0
Downslope length	mm	5	5	5	5	10	2.5	3
Downslope	sec	0.5	1	1	1	1	0.3	0.3
End Current I-E	A	20	40	40	40	150	40	55
post-weldtime	sec	0	0	0	0	0.1	0.3	0.1
Gas after-flowtime torch	sec	2	2	2	2	8	8	2
Welding Machine Parameter								
Type of Operation	DC- / AC	AC	AC	AC	AC	AC	AC	DC-
Second Current	%	0	0	0	0	0	70	90
Frequency	Hz	0.2	0.2	0.2	0.2	0.2	65	90
DC-Balance	%	10	10	10	10	10	20	10
AC-Balance	%	2	2	2	2	-1	2	0
Pulse	on / off	off	off	off	off	off	off	off
Coldwire Parameter								
Coldwire	on / off	off	off	off	off	off	off	off
Coldwire delay time	sec	0	0	0	0	0	0.1	0
Speed Wirefiller	cm/min	1	1	1	1	1	50	1
No. Of switch length	No.	0	0	0	0	0	0	0
Downslope length	mm	0	0	0	0	0	0	0
Wire Holdtime	sec	0	0	0	0	0	0.2	0
Wire Leadtime	sec	0	0	0	0	0	0	0
Tack Parameter								
Tack	on / off	off	off	off	off	off	off	off
No. Of Tacks	No.	1	1	1	1	2	5	1
Tack position 1	mm	290	290	290	290	500	280	0
Tack position 2	mm	0	0	0	0	250	250	0
Tack position 3	mm	0	0	0	0	0	200	0
Tack position 4	mm	0	0	0	0	0	150	0
Tack position 5	mm	0	0	0	0	0	100	0
Tack Time	sec	2	2	2	2	3	2	0
Tack Current	A	70	70	70	70	200	60	3
Gas after Flowtime	sec	3	3	3	3	0	1	0
Coldwire	on / off	off	off	off	off	off	off	off
Coldwire Delaytime	sec	0	0	0	0	0	0	0
Coldwire Speed	cm/min	1	1	1	1	1	1	1
Machine Parameter								
Parkposition	on / off	off	off	off	off	off	on	off
Partstop position	mm	190	190	190	190	192	90	90
Back sheilding gas	on / off	off	off	off	off	off	off	off
Carrie gas (sheilding nozzle)	on / off	off	off	off	off	off	off	off
Direction	fr>re / re>fr	fr>re	fr>re	fr>re	fr>re	fr>re	fr>re	fr>re